

PB 805







Flat chisel

- for working on unhardened steel, concrete, masonry, for removing welding beads, mortar residues, etc.
- octagonal shaft with sharp blade, avoid heating up to over 200 °C when sharpening
- chrome-plated, permanent corrosion protection
- tempered drive head, prevents splinters according to applicable standards
- high hardness, ensures exceptional retention of sharpness and long service lives
- special alloy based on spring steel, hard and tough for long service life
- laser-marked serial number, lifetime guarantee
- pay attention to the safety regulations when working with striking tools: www.pbst.ch/safe

Cinzel plano

- para trabajar acero no endurecido, mampostería, hormigón, retirar restos de soldadura, de mortero, etc.
- vástago octogonal, filo cortante, en el rectificado evitar temperaturas de más de 200 °C
- protección contra el óxido durable, cromada
- cabezal de impacto retemplado, impide la fragmentación según la normativa
- la extraordinaria dureza garantiza una gran durabilidad de corte y una larga vida útil
- aleación especial de acero para resortes, dura y resistente para una larga vida útil
- rotulación láser con n.º de serie, garantía de por vida
- observe siempre las normas de seguridad cuando trabaje con herramientas de percusión: www.pbst.ch/safe



						
PB 805.10	120	8	10	45	10	7 610733 005710
PB 805.12	130	10	12	75	10	7 610733 005727
PB 805.14	150	10	14	87	10	7 610733 005734
PB 805.18	165	12	18	139	10	7 610733 005741
PB 805.22	180	14	22	208	10	7 610733 005758
PB 805.25	200	16	25	294	10	7 610733 005765